




FOLDABLE CONSOLE



Brushed Stainless Steel
124 L x 35 W x 60 H cm

Screws, Cap Nuts & Adjustable feet

Hex key &
Socket wrench (not included)



1.





Wear gloves when handling and assembling the table to avoid fingerprints on the untreated surface. Any adhesive residue from the protective film can be removed with white spirit, thinner, or nail polish remover.

Carefully unfold the frame to a 90° angle until the sides are fully extended and stable. Screw the four adjustable feet into the bottom of the frame and adjust them to ensure the table stands level.



2.





Carefully slide the bottom shelf into place inside the frame. Secure it by inserting the screws through the frame from inside and tightening them with the cap nuts on the opposite side, using the included hex key. A socket wrench can be used as well for extra grip, but take care not to scratch the surface. We recommend assembling this step together with another person to keep the shelf level and aligned while fastening.



Hex key &
Socket wrench (not included)



3.



Repeat the same procedure with the top shelf. Note that the screws need to be placed from the outside and secured with the cap nuts on the opposite side.



Hex key &
Socket wrench (not included)

